


P:\CAD\24901-BAF\Building Permit\PL-E02.dgn
2/4/2005




NOTES:

- REPLACE EXISTING STARTER AND MCP FOR OTI-BLV-02 WITH A 225AF, 175AT, 480V, 65KAIC, 3-POLE MOLDED CASE CIRCUIT BREAKER.
- REPLACE EXISTING STARTER AND MCP FOR OTI-CPS-01 WITH A 20AF, 20AT, 480V, 65KAIC, 3-POLE MOLDED CASE CIRCUIT BREAKER.
- FUTURE RELOCATED FEED. REFERENCE ELECTRICAL SITE PLAN FOR RELOCATION.
- PROVIDE 3-POLE CIRCUIT BREAKER.
- PROVIDED BY OTHERS.
- PROVIDE HOA SWITCH AND RUN LIGHT.
- PROVIDED BY EQUIPMENT MANUFACTURER.

PANELBOARD SCHEDULE															
CKT			VA	VA	VA	BRKR	CKT			VA	VA	VA	BRKR		
NO	USAGE	QTY	PHASE A	PHASE B	PHASE C	A/PLS	NO	USAGE	QTY	PHASE A	PHASE B	PHASE C	A/PLS		
1	TRANSFORMER D		5000			30/3	2	BIOSTYR		11085			50/3		
3	↓			5000		-	4	↓			11085		-		
5					5000	-	6	↓				11085	-		
7	BIOFOR UNIT-C		6928			30/3	8	BIOFOR UNIT-N		6928			30/3		
9	↓			6928		-	10				6928		-		
11	↓				6928	-	12	↓				6928	-		
13	MINIPOWER ZONE XFMR		1260			20/2	14	SUMP PUMP PANEL		333			20/3		
15	↓			540		-	16	↓			333		-		
17	SPARE					20/3	18	↓				333	-		
19						-	20	SPARE					30/3		
21	↓					-	22	↓					-		
23	SPACE						24	↓					-		
PHASE VA SUBTOTALS			13188	12468	11928		PHASE VA SUBTOTALS			18346	18346	18346			
							PHASE VA TOTALS			31534	30814	30274			
							PANELBOARD VA TOTALS						92622		
							PANELBOARD AMPS TOTALS						111.4 A		
PANEL NO: DP-1 EQUIPMENT TAG: LOCATION: VOLTAGE: 480 VAC MAIN BREAKER: 225A BUS SIZE: 225A MOUNTING: TYPE: NEMA 3R PHASE: 3 PHASE WIRE: 3 SHORT CIRCUIT: 65 KAIC															

PANELBOARD SCHEDULE											
CKT		VA		VA	BRKR	CKT	VA		VA	BRKR	
NO	USAGE	QTY	PHASE A	PHASE B	A/PLS	NO	USAGE	QTY	PHASE A	PHASE B	A/PLS
1	RECEPTACLES		540		20/1 GFCI	2	RECEPTACLES		720		20/1 GFCI
3	RECEPTACLES			540	20/1 GFCI	4	SPARE				20/1
5	SPARE				20/1	6	SPARE				20/1
7						8					
PHASE VA SUBTOTALS			540	540			PHASE VA SUBTOTALS		720		
							PHASE VA TOTALS		1260	540	
							PANELBOARD VA TOTALS				1800
							PANELBOARD AMPS TOTALS				7.5 A
PANEL NO: PNL P						MOUNTING: TYPE: NEMA 3R					
EQUIPMENT TAG:						PHASE: 1PHASE					
LOCATION:						WIRE:					
VOLTAGE: 120/240 VAC						SHORT CIRCUIT: 22 KAIC					
MAIN BREAKER: 40A											
BUS SIZE: 40A (MIN)											



WARNING
0 1/2 1
IF THIS BAR DOES NOT MEASURE 1" THEN DRAWING IS NOT TO SCALE.

BROWN AND CALDWELL			
SUBMITTED:	PROJECT MANAGER	DATE:	
APPROVED:	BROWN AND CALDWELL	DATE:	
APPROVED:		DATE:	
SCALE	HORIZONTAL	NONE	
	VERTICAL	NONE	

METROPOLITAN WASTEWATER
DEPARTMENT
City of San Diego



DRAWING STATUS									
NO.	DATE	REQ.	REVISION	DESCRIPTION	DRAWN	CKD	APD	PE	EM

POINT LOMA WASTE WATER TREATMENT PLANT BIOLOGICAL AERATED FILTER PILOT STUDY					
ELECTRICAL SINGLE LINE DIAGRAM AND PANELBOARD SCHEDULES					
CITY OF SAN DIEGO, CALIFORNIA SHEET 20 OF 22 SHEETS				WATER W.O.	NA
				SEWER W.O.	NA
PROJECT MANAGER		DATE			
DESCRIPTION	BY	APPROVED	DATE	FILMED	
					DESIGN ENGINEER
					CONTROL CERTIFICATION
					188-1692
					LAMBERT COORDINATES
CONTRACTOR		DATE STARTED			
INSPECTOR		DATE COMPLETED			
00000-20-D					

EXHIBIT B

PILOT TEST UNIT SPECIFICATIONS



Kruger Products
401 Harrison Oaks Blvd.
Ste. 100
Cary, NC 27513

TELEPHONE 919-677-8310
FACSIMILE 919-677-0082

Technical Addendum to Proposal

USFilter/Kruger Products is pleased to provide an equipment list and technical specifications for the Biostyr[®] pilot test unit to be used at the referenced site.

BIOSTYR[®] Pilot Unit

Equipment

The Biostyr[®] pilot unit contains the following equipment:

- One (1) 36" OD tank
- Media (4.5 mm polystyrene beads)
- One (1) pH meter and transmitter
- One (1) dissolved oxygen meter and transmitter
- Two (2) flow meters and transmitters
- One (1) temperature sensor and transmitter
- One (1) 1700 gallon fiberglass backwash tank
- One (1) 0.75 HP/1725 RPM motor powering an agitator for backwash tank mixing
- One (1) 8.6 SCFM @ 100 PSIG air compressor with 60-gallon horizontal receiver
- One (1) compressed air dryer
- One (1) process air flow controller
- All necessary air distribution piping both for air grid and valves
- Two (2) air actuated butterfly valves with actuator and solenoid
- Two (2) manual butterfly valves for manual flow adjustments
- Two (2) submersible non-clog centrifugal pumps
- Two (2) check valves ensuring forward flow
- One (1) SCADA system to control and monitor process

Technical Specifications

Dimensions

Biostyr[®] tower's assembled height is 28'6" in height by 8' wide by 8' in Length.

Biostyr[®] tower's shipping height is 18'6".

Biostyr[®] tower weighs approximately 10,000 LBS without water and 13,245 LBS loaded with water.

Control Building is 8'2" in height by 7'7" wide by 12'3" in length

Backwash drain tank is 6'6" OD fiberglass tank and weighs approximately 240 LBS without water and 15,000 LBS with water



Kruger Products
401 Harrison Oaks Blvd.
Ste. 100
Cary, NC 27513

TELEPHONE 919-677-8310
FACSIMILE 919-677-0082

Capacity

Water:

Nominal Flow: 16 GPM

Minimum Flow: 7 GPM

Air:

Forward flow: 2 CFM @ < 10 psi

Backflush: 5 CFM @ < 10 psi

Hydraulic Connections:

Influent:

Customer supplies feed tank. Pre-wired, pre-piped pump is placed in feed tank. US Filter provides approximately 10' of flex hose for immersion in feed tank. Customer provides a standard ¾" hose bib and sufficient garden hose to reach Biostyr[®] tower.

Effluent:

One (1) 3", 150 LB flange connection for backwash drain tank overflow

One (1) 3" NPT valve to drain 1700 gallon backwash drain tank

One (1) 4", 150 LB flange connection for water back flush discharge

One (1) ¾" nipple connection for compressed air dryer discharge

Electrical

Customer provides 480 volt, 100 Amp service.

Foundation

Customer provides level paved surface to support the Biostyr[®] tower, the backwash drain tank, and field office.


Protocol, Data and Visitation

Pilot study protocol must be agreed upon by both the client/engineer and US Filter prior to the start of treatment.

US Filter reserves the right to all data collected (including Biostyr[®] running conditions and laboratory samples) by the client/engineer or US Filter. All data shall be shared between the client/engineer and US Filter at the time the data is collected or available.

US Filter reserves the right to use any collected data.

US Filter reserves the right to bring visitors to the pilot unit throughout the course of the study.




DRAWING
42809811-385F14

DRAWING
42809811-385F15

FEED PUMP/HOSE TO TOWER
PROVIDED BY
US FILTER/KRUGER PRODUCTS

4", 150 LB BACKWASH
CONNECTION
CUSTOMER TO ROUTE
TO APPROPRIATE LOCATION



THE PRESENCE OF A PROFESSIONAL ENGINEERS SEAL ON THIS DRAWING INDICATES THAT A SIGNED AND SEALED ORIGINAL IS ON FILE.

				COMPANY CONFIDENTIAL				DESIGNER	DATE	TITLE
				ANY THIS DOCUMENT AND ALL INFORMATION CONTAINED HEREIN ARE THE PROPERTY OF THE US FILTER AND/OR ITS AFFILIATES ("USF"). THE DESIGN CONCEPTS AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY TO USF AND ARE SUBMITTED IN CONFIDENCE. THEY ARE NOT TRANSFERABLE AND MUST BE USED ONLY FOR THE PURPOSE FOR WHICH THE DOCUMENT IS EXPRESSLY LOANED. THE USER MUST NOT BE DISCLOSED, REPRODUCED, LOANED OR USED IN ANY OTHER MANNER WITHOUT THE EXPRESS WRITTEN CONSENT OF USF. IN NO EVENT SHALL THE USER BE USED IN ANY MANNER DETRIMENTAL TO THE INTEREST OF USF. ALL PATENT RIGHTS ARE RESERVED. UPON THE DEMAND OF USF, THIS DOCUMENT, ALONG WITH ALL COPIES AND EXTRACTS AND ALL RELATED NOTES AND ANALYSES, MUST BE RETURNED TO USF OR DESTROYED AS INSTRUCTED BY USF. ACCEPTANCE OF THE DELIVERY OF THIS DOCUMENT CONSTITUTES AGREEMENT TO THESE TERMS AND CONDITIONS.				SDD	06.18.03	BIOSTYR PILOT SYSTEM SYSTEM LAYOUT
								CHECKER	DATE	CLIENT
								ENGINEER	DATE	
								MANAGER	DATE	
								FILE:		
								SCALE:	NONE	
								US Filter		
								KRUGER PRODUCTS 401 HARRISON OAKS BLVD CARY, NC 27513 (919) 677-8310 FAX (919) 677-0082		
								CLASSIFICATION	PROJECT No.	DRAWING
									42809811	385M001
										SHEET
										4 OF 4
										RE
										0

rev	date	description	dwn	chk	appv

GRAPHICAL SCALE	0	0.5	1	2	3	6
-----------------	---	-----	---	---	---	---

INTERNAL REF NO: IF BAR IS NOT 1", ADJUST SCALE ACCORDINGLY



ONDEO Degremont, Inc.

Technical Data Sheet Biofor™ Process (2-Foot Column) Single Stage Unit

Description:

The Biofor™ Pilot Plant accurately simulates the Biofor™ process, a fixed-film aerobic biological treatment system. It operates on the principle of an upflow co-current flow of process and air. The media, Biolite, is an expanded clay material with a high specific area to provide a surface for the biomass to attach to and filter suspended solids.

Weight:

- 10,000 lbs. (shipping)
- 14,000 lbs. (operating)

Overall Plan Area:

- 7'0" x 10'-0" (skid)
- 8'0" diameter x 5'8" (clearwell)

Overall Height:

- 22'-0"

Electrical Requirements:

- 480V, 3 Phase, 25 amps
- Raw Water Pump: 3.0 hp, 60 Hz
- Backwash Pump: 1.5 hp, 60 Hz
- Scour Air Compressor: 2 hp, 60 Hz
- Process Air Compressor: 1 hp, 60 Hz

Connections:

- Influent: 2" half coupling
- Effluent: 4" male NPT
- Service Water: 0.75" female connection



**ONDEO
Degremont,
Inc.**

**Technical Data Sheet
Biofor™ Process
(2-Foot Column) Single Stage Unit**

Process Data:

- Column Area: 3.1 ft²

Parameters	Process	Carboneous Pollution Removal	Nitrification	Denitirification
<u>Raw Water</u> m/h (USGPM/ft ²)	Minimum Maximum	4 (1.64) 20 (8.20)	4 (1.64) 20 (8.20)	-- 30 (12.26)
<u>Process Air</u> m/h	Minimum Maximum	4 15-20	4 35	-- --
<u>Loadings</u> kg/m ³ /d	(Maximum) COD Suspended Solids Total BOD ₅ N-NH ₄ NO ₃ -N	15 5 6 -- --	8 3 3 1.6 --	-- -- -- -- 4
<u>Filter Run</u> hours	Maximum	48	48	24
<u>Head Loss</u> (per meter of media) height m WC (in WC)	(Maximum)	0.4 (16)	0.4 (16)	--



ONDEO Degremont, Inc.

Technical Data Sheet Biofor™ Process (1-Foot Column) Single Stage Unit

Description:

The Biofor™ "DN" Pilot Plant accurately simulates the Biofor™ "denitrification" process, a fixed-film anoxic biological treatment system. It operates on the principle of an upflow flow. The media, Biolite, is an expanded clay material with a high specific area to provide a surface for the biomass to attach to and filter suspended solids.

Weight:

- 10,000 lbs. (shipping)
- 12,000 lbs. (operating)

Overall Plan Area:

- 7'0" x 10'-0" (skid)
- 8'0" diameter x 5'8" (clearwell)

Overall Height:

- 22'-0"

Electrical Requirements:

- 480V, 3 Phase, 25 amps
- Raw Water Pump: 3.0 hp, 60 Hz
- Backwash Pump: 1.5 hp, 60 Hz

Connections:

- Influent: 2" half coupling
- Effluent: 4" male NPT
- Service water: 0.75" female connection



**ONDEO
Degremont,
Inc.**

**Technical Data Sheet
Biofor™ "DN" Process
(1-Foot Column) Single Stage Unit**

Process Data:

- Column Area: 0.78 ft²

Parameters	Process	Carboneous Pollution Removal	Nitrification	Denitrification
Raw Water m/h (USGPM/ft ²)	Minimum Maximum	4 (1.64) 20 (8.20)	4 (1.64) 20 (8.20)	-- 30 (12.26)
Process Air SCFM	Minimum Maximum	4 15-20	4 35	-- --
Loading kg/m ³ /d	(Maximum) COD Suspended Solids Total BOD ₅ N-NH ₄ NO ₃ -N	15 5 6 -- --	8 3 3 1.6 --	-- -- -- -- 4
Filter Run hours	Maximum	48	48	24
Head Loss (per meter of media) height m WC (in WC)	(Maximum)	0.4 (16)	0.4 (16)	--

