A Guide for Digital Conversion **Transparency Scanning**



A Guide for Digital Conversion | Transparency Scanning

03
05
10
15

Power On Epson Expression 12000XL

Located on the left side of the front of the machine is the **POWER** button. Press the grey button to start the scanner.

It will make a beeping sound and a **green light** will illuminate on the front of the machine, indicating it is on and ready to use (see image).

This light needs to stay green



Lift Open Lid of Epson Expression 12000XL

Make sure the scanner glass is clean and free of dust. If there any items were left in the scanner, give it to a staff member.

Remove the Document Mat from *Epson Expression* 12000XL

Grasp the white reflective Document Mat by its top edge and slide it upward to free the bottom edge. Lower the mat slightly to free the tabs at the top edge, then remove the mat. Place the mat in the storage pocket located on the top of the scanner lid.



4 Launch the 'Epson Scan 2' Program

Double-click on the **'Epson Scan 2'** icon located on your desktop to open the software (see image).



Once your device is on and the software is ready to go, it's be time for you to get your media prepared to scan.

5 Prepare the Epson Expression 12000XL *Transparency Unit*

Open the Transparency Unit and use a soft cloth to wipe the scanner glass. Place the **'Transparency Guide'** at the top edge of the scanner glass. There will be two circular indents. Ensure that the guide aligns with these two indents (see images).



SΓ

5 Create your specified folder for saved scans

After powering on the Epson Expression 12000XL and ensuring that the scanner is ready to be used, you will want to create a new folder (to place your new scans into) on the desktop. Try naming the folder something that is relatively easy for you to recognize, but that is also easy to find (hence, creating the folder via the desktop). Please view the images below for reference:



1) Go to the desktop, right-click, and **2)** select 'New folder' from the drop-down list. After doing this, the text should automatically be highlighted blue; indicating that you may type. If it is not, right-click on the folder you just created titled 'New Folder, and click on 'rename' from the list. **3)** Replace the 'New Folder' title name of your new folder with one of your choosing.

Note: we recommend renaming the folder something that is in relation to your scans or that is easy to remember

7 Prepare and Setup Your *media to be scanned*

First, you'll want to ensure that you have the correct film holder (if needed). There are 4 different types of film holders. They are as shown:



a) slides



b) 35 mm film strips



c) 4 x 5 inch film



d) Medium format film 120/220





Load your slides according to the film holder. You will want to set the shiny side face-down towards the floor (the side which usually has no logos or text), with the dull, mirrored side of the slide face up towards you. Lastly, you will want to ensure that your slide image fills in the provided outline *as much as possible* for the best results.



Try to fill in this area with Your photo

This side will be facing you



This side will be facing away from you



Setup

SΓ

8b Prepare and Setup Your **35mm film strips**

Load your strips according to the strip holder. You can only load four film strips at a time into the strip holder. You will first need to remove the covers. You will want to ensure that your film strips fit into their holders, without overlapping the hollowed area. Lastly, remember to clasp the covers back over each film strip, to ensure that they will not move around.





8c Prepare and Setup Your *4 x 5 inch film*

Load your 4 x 5 photos according to the film holders. You will want to set the photos face-down towards the floor with the plain white side facing towards you. Lastly, you will want to ensure that your 4 x 5 inch films fill in the provided outline *as much as possible* for the best results.



You will want to ensure that your film/photos fit into this area.



Ensure that you clamp the holders back over your 4 x 5 film to

SC

8d Prepare and Setup Your *medium format 120/220 film*

Load your medium format into the holder. You will want to set the images face-down, with the plain, white side of the medium format facing up towards you. Lastly, you will want to ensure that you clamp the cover closed and have the images fill in *as much of the holder as possible* for the best results.

> Remember to snap the holder closed, so that the medium formatted photos do not move around.

Load your medium format into the holder. You will want to set the images face-down, with the plain, white side of the medium format facing up towards you.

SC

8e Prepare and Setup Your *formats on the scanner*

Load your medium format into the correct holder. You will want to ensure that you clamp the holders closed and have all images fill in *as much of the holder as possible* for the best results. After loading your holder, you will need to place it onto the scanner glass against the transparency guide. There will be an arrow on the guide, and an arrow on each holder. Ensure that both of these arrows are facing each other. Please refer to the images below:



Select and Edit Your Scan Settings

Before you begin scanning, you will need to select your preferred settings for your media format. *Your Epson Scan 2 settings for your media* should look something like this:

Epson Scan 2 —		Х
Scanner: EPSON Expression 12000XL (USB)		\sim
Scan Settings: Default Setting		\sim
Mode: Photo Mode		\sim
Main Settings Advanced Settings		
Document Source:Transparency Unit	~	
Document Type: Color Negative/Positive Film	~	
Image Type: 24/48-bit Col-	~	
Resolution: 600/1200 v dpi		
Standard	~	
		_
Image Format : JPEG/PNG/TIFF		~
File Name : Folder : Desktop		~
Folder : Desktop		~
🕜 💭 Preview	Scan	

Note: You can change settings for the file name by selecting "Settings" from the File Name dropdown list.

Preview Your Scans and *make any adjustments*

Make any necessary adjustments in the **Settings** or **Advanced Settings** tab. Click the '**Preview'** button to preview your scans. Repeat this step as many times as needed.



- (a) **Close:** Close the preview panel
- (b) **Zoom:** Zoom in on a manually selected photo (will preview it)
- (c) Marquee Deletion: Removes the last made marquee from the selection tool
- (d) Marquee Copy: copies the content within the selected marquee
- (e) Select All: Selects all photos
- (f) Auto Exposure: Automatically adjusts the lighting of the photos
- (g) Auto Focus: Automatically adjusts the focus of the photos
- (h) Manual Focus: Allows the user to manually set the areas of focus points for photos

Separating Images When scanning multiple images, such as slides, make sure the checkbox next to "Thumbnail" is selected. This will allow images to be scanned as separate files.

Scanner :	EPSON Expression 12000XL(USB)	C Thumbnail
Scan Settings :		
	Photo Mode	
Main Settings Adv	anced Settings	
Document S	ource : Transparency Unit	
Document	Type : Color Positive Film 🔻	
Image	Type : 24-bit Color 🗸	
Reso	lution : 1200 🔻 dpi	
Scanning Q	uality : Standard 👻	
Folder :	img20221117_15504030.jpg	
?	Preview Scan	Scan Count : 4

SE

Confirm Your Settings and Finalize Your Scans

Once you are satisfied with your preview, click the '**Scan'** button to begin saving your scan. Your photos will be automatically saved to the previously specified destination folder when the scan is finished.

Note: the total scanning time will be dependent upon the following: how many images you are scanning, your dpi settings, your resolution settings, and the quality settings. Generally, the higher the quality and dpi, the longer it will take to finish scanning your photos.

Remember to select your image format!



Image Format : JPEG/P	NG/TIFF	~
File Name :		~
Folder : Desktop		~
o 🗘	Preview	Scan

Don't forget to select 'Scan'—NOT PREVIEW!

Finalizing Your Scans: Saving & Transferring

Once you are finished, remove all transparency holders and take out your original materials. Remove the Transparency Guide from the scanner glass and return the Document Mat to the Transparency Unit. Close the scanner lid and press the power button to shut down the scanner.

Close 'Epson Scan 2' and Eject Your USB

When you are finished, close out of *Epson Scan 2*. Right-click your personal storage device and select "**EJECT**" in order to safely remove it.

Locate your USB drive	Expand
under <i>'Computer'</i>	Turn on BitLocker
Computer	Open AutoPlay
Local Disk (C)	Open in new window
Removable Disk	Share with
	Open as Portable Device
G	Scan E:/
	Format
	Eject
	Cut
Select <i>'Eject.'</i> A window should	Сору
pop-up letting you know that	Rename
your USB is safe to remove.	New
	Properties

Finished!

You have now successfully scanned your photos! Congratulations on your

new digital images!



14

Remember to do the following:

- Take your external device and any personal belongings with you
- Delete your photos off the computer, and empty the recycling bin